



- Audit
- Inventory
- Service
- Diagnostic
- Settings
- Filling

**A Audit**

General data

- | Machine number
- | Number of printouts/readouts
- | Number of power resets
- | Tube contents
- | Recycler content

Vends

- | Sales of all payment sources
- | Cash sales
- | Cashless sales
- | Token sales
- | Free vends
- | Free vends with token
- | Test vends
- | Discounts
- | Sales per selection line

Flow of money

- | Coin data
  - | Coins to cash-box
  - | Coins to tube
  - | Change paid out
  - | Change paid out from Hopper
  - | Coins to tube manual filling
  - | Coin paid out manually
  - | Cash overpay
  - | Credited from machine
  - | Coin counter
    - Counter: Accept
    - Counter: In tube
    - Counter: Paid out
- | Bill data
  - | Accepted bills
  - | Bills to recycler
  - | Bills paid out
  - | Bills to recycler manually
  - | Bills paid out manually
- | Cashless data
  - | Debited from cashless
  - | Credited to cashless
  - | Discounts from cashless
  - | Token from cashless
- | Token
  - | Accepted tokens
  - | Token overpay
  - | Freevend token

**B Inventory**

Assignment, coin cassette

Change stock

Tube counters A-F

*You may use inventory keys A-F to pay out tube coins*

**C Service**

Show payout combination

Coin Management

- | Payout statistic
- | Status of analysis
- | Proposals for optimization

Token Teach

- | Token teach
  - | Token A
  - | Token B
  - | Token C
- | Token delete
  - | Token A
  - | Token B
  - | Token C

Empty tubes

Hopper

- | Hopper Inventory
- | Hopper manual fill mode
- | Reset Hopper counter

Airport ready -> send SMS

**D Diagnostic**

Validator module

Changer module

Payout module

Audit module

Display modul

Hopper

Motor sensors

Sensor left

Sensor middle

Sensor right

**E Settings**

**F Filling**

Assignment, coin cassette

Change stock

Tube counters A-F

*You may refill the cassette by inserting the tube coins*



**i** For more details about configuration and service work on the coin changer please refer to the *c<sup>2</sup> Configuration and Service manual* ([www.cranepi.com](http://www.cranepi.com), Support).

